


PRAKTIKUM 6

Wiring :



UNO	LED
5	Anoda
4	Anoda
3	Anoda
2	Anoda
GND	Katoda

Code :

```
void setup() {  
  pinMode(2,OUTPUT);  
  pinMode(3,OUTPUT);  
  pinMode(4,OUTPUT);  
  pinMode(5,OUTPUT);  
  digitalWrite(2,LOW);  
  digitalWrite(3,LOW);  
  digitalWrite(4,LOW);  
  digitalWrite(5,LOW);  
}
```

```
void loop() {  
  digitalWrite(2,HIGH);  
  digitalWrite(3,LOW);  
  digitalWrite(4,LOW);  
  digitalWrite(5,LOW);  
}
```

```
delay(500);  
digitalWrite(2,LOW);  
digitalWrite(3,HIGH);  
digitalWrite(4,LOW);  
digitalWrite(5,LOW);  
delay(500);  
digitalWrite(2,LOW);  
digitalWrite(3,LOW);  
digitalWrite(4,HIGH);  
digitalWrite(5,LOW);  
delay(500);  
digitalWrite(2,LOW);  
digitalWrite(3,LOW);  
digitalWrite(4,LOW);  
digitalWrite(5,HIGH);  
delay(500);  
}
```